

French Drain

Steps:

- Lay out and mark location of drain
- Excavate marked area
- Install a layer of support fabric around complete perimeter of drain area leaving adequate material to wrap top of drain area to prevent contamination of drain.
- Install stone aggregate in drain area and wrap with support fabric, installing perforated pipe when necessary
- Where new underdrain system intersects existing structure or storm sewer line, tie into existing system to allow drainage of underdrain systems.
- Install specified finish

