

Speed Bumps

Steps:

- Lay out and mark area for placement of speed bumps
- Clean area of all dirt and debris
- Notch existing asphalt surface to alleviate speed bump displacement
- Tack coat area of installation using liquid asphalt
- Install hot mix surface asphalt to a maximum height of 3-1/2" at the apex and a width of 18"
- Apply a seal of liquid asphalt to the adjoining edge of the installation to help prevent moisture penetration
- Apply heavy-duty reflective traffic paint sufficient to identify the speed bump.

